

Parts List - Small sized series 小型机芯

PARTS NAME	CHINESE	Qty	YL50A1	YL50A2
Battery Connection (-)	負極片	1	4270 505	←
Battery Connection (+)	正極片	1	4271 527	4271 525
Centre Wheel	中心輪	1	0221 932	0221 931
Circuit Block	電路板	1	4000 752	←
Circuit Block Spacer	電路板墊	1	4408 931	←
Clutch Wheel	豬籠輪/離合輪	1	0282 931	←
Coil Block	線圈	1	4002 505	←
Dial Washer	針片	1	0491 930	←
Fourth Wheel	4號輪	1	0241 930	←
Hour Wheel	時輪	1	0271 932	0271 931
Insulator For Battery Connection (-)	負極電池絕緣片	1	4216 506	←
Minute Wheel	度數輪/分輪	1	0261 930	←
Rotor Stator	轉子甲板/定子	1	4239 505	←
Screw(B)	螺絲(B)	4	0022 335	←
Screw(C)	螺絲(C)	1	0022 346	←
Setting Lever	押掣竿	1	0383 930	←
Setting Lever Spring	押掣彈弓	1	0389 931	←
Insulator for Battery	電池絕緣片	1	4216 505	←
Spacer For Setting Lever	押掣罩	1	0767 931	←
Step Rotor	轉子	1	4146 505	←
Third Wheel	3號輪	1	0231 930	←
Train Wheel Bridge	夾板	1	0125 936	0125 933
Winding Stem	柄軸/巴心	1	0351 931	←
Yoke	換日竿/橫擔	1	0384 931	←

Parts List - Slim 2&3 hands series 2&3 針薄裝机芯

PARTS NAME	CHINESE	Qty	VX00A1	VX01B1	VX10A1	VX11B1	VX50E1	VX51E1
Battery Connection (-)	負極片	1	4270 538	←	←	←	4270 891	4270 904
Battery Connection (+)	正極片	1	None	None	None	None	4268 743	4268 745
Centre Wheel	中心輪	1	0221 813	0221 809	0221 814	0221 819	0221 905	0221 908
Circuit Block	電路板	1	4000 539	4000 554	4000 539	4000 554	4000 761	4000 633
Circuit Block Cover	電路板蓋	1	4457 ***	←	←	←	None	None
Clutch Wheel	豬籠輪/離合輪	1	0282 804	←	←	←	0282 890	←
Coil Block	線圈	1	4002 536	4002 504	4002 536	4002 504	4002 760	4002 905
Dial Washer	針片	1	0491 735	←	←	←	←	←
Fifth Wheel	5號輪	1	None	0701 805	None	0701 805	None	0701 904
Fourth Wheel	秒針輪	1	None	0241 509	None	0241 512	None	0241 908
Hour Wheel	時輪	1	0271 813	0271 803	0271 818	0271 819	0271 905	0271 908
Insulator For Battery (A)	電池絕緣片(A)	1	None	None	None	None	None	4216 890
Insulator For Battery (B)	電池絕緣片(B)	1	None	None	None	None	None	4216 907
Minute Wheel	度數輪/分輪	1	0261 808	0261 818	0261 809	0261 819	0261 905	0261 908
Rotor Stator	轉子甲板/定子	1	4239 536	4239 539	4239 536	4239 539	4239 891	4239 901
Screw	螺絲	3	0022 221	←	←	←	0022 247	←
Setting Lever	押掣竿	1	0383 806	←	←	←	0383 176	←
Setting Wheel	小鐵車/撥針輪	1	0281 807	0281 806	0281 807	0281 806	0281 904	←
Step Rotor	轉子	1	4146 557	4146 547	4146 557	4146 547	4146 890	←
Third Wheel	3號輪	1	0231 811	0231 806	0231 811	0231 806	0231 905	0231 904
Train Wheel Bridge	夾板	1	0125 809	0125 502	0125 809	0125 502	0125 905	0125 904
Train Wheel Setting Lever	輪組止動竿	1	None	0391 806	None	0391 806	None	0391 890
Winding Stem	柄軸/巴心	1	0351 807	←	0351 819	←	0351 178	←
Yoke	換日竿/橫擔	1	0384 807	←	←	←	0384 890	←

Hands Height Variety

			VX00A2	VX01B2	VX10A2	VX11B2
Hour Wheel	時輪	1	0271 829	0271 808	0271 634	0271 635
Centre Wheel	中心輪	1	0221 829	0221 808	0221 597	0221 598
Fourth Wheel	秒針輪	1	None	0241 515	None	0241 568