

A COMPANY OF THE **SWATCH GROUP**

CALIBRE

1000-1001-1002

1000 27.90 RA SC PC CAL CORR INST STS AM 17 j. 1001 27.90 RA SC PC CAL CORR INST STS AM BULL. 20 j. 1002 27.90 RA SC PC CAL CORR INST STS AM 20 j.

ø 27.90 mm	1 2 3
Movement height	4.00 mm
Power-reserve	50 h
Jewel number	17/20/20
Frequency	28'800 A/h
Angle of lift	52°



At 28800 vibrations per hour instant date correction and stop second.

The type of construction allows the manufacture of a very flat movement having a high chronometric performance with a large power reserve, which is also easy to repair.

A very large barrel supplies the energy to the balance oscillating at 28800 vibrations per hour.

The diameter of the balance at this frequency becomes clearly smaller than at the usual frequency of 19 800 vibrations, but its internal energy and consequently its timing properties remains very high.

The slimness of this calibre has been obtained by using the vacant space left by the smaller balance for lodging the automatic block, and also by utilising a centre wheel positioned offcentre.

The functions of the winding stem have been chosen in order to easily correct the date without changing the position of the hands.

During the hand setting operation, the second hand is stopped automatically.

The different functions of the winding stem are as follows:

Position 1 manual winding

Position 2 rapid date correction

Position 3 stop-second, and hand setting

English

Specifications

Dimensions

Total diameter 28.40 mm

Casing-diameter 27.90 mm

Height of movement 4.00 mm

Diameter of screw pitch of winding stem 0.90 mm

No. of vibrations

 $28'800~{\rm per}$ hour. For verification the position 14'400 A/h of any timing machine can be used.

Lifting angle

Angle of lift of balance 52°.

Running time

The stainless alloy mainspring assures a running time of more than fifty hours.

Ebauche

consists of:

1 plate

1 barrel bridge

1 train wheel bridge

1 pallet bridge

1 balance bridge

2 bridges for the self-winding mechanism, forming a block independent of the movement

1 calendar plate

Jewelling Cal. 1000

17 jewels as follows:

12 jewels for gear-train and escapement 2 balance end-stones

2 pallet jewels and 1 impulse-pin

1 beryllium bronze bushing at upper pivoting point of arbor in barrel bridge

Cal. 1001 Chronometer

20 jewels as follows:

12 jewels for gear-train and escapement

2 balance end stones

2 pallet stones and 1 impulse-pin 2 jewels for winding gear

1 jewel for driving gear for ratchet wheel, upper

1 beryllium bronze bushing at upper pivoting point of arbor in barrel bridge.


Cal. 1002

This calibre has the same number of jewels as 1001, but is not a Chronometer.

Barrel

The barrel-cover is snapped on over the outside of the barrel-drum. A slip-ring of similar alloy as the mainspring is placed inside the barrel-drum. This allows the use of a dry lubricant which does not deteriorate and remains stable even if the watch is not in use.

In case the barrel needs to be cleaned, also replace the slip-ring no. 1000.7221 and slightly relubricate the mainspring with selflubricant 3.03.





Gear-train

The centre wheel is positioned off centre. The cannon pinion of the third wheel is tightly pressed onto its pivot-shank and meshes with the centre cannon pinion which consists of two parts-wheel and pinion.

The cannon friction is assured in between the wheel and pinion.

It is recommended to support the upper third wheel pivot whilst placing the small cannon pinion.





Functions of the winding stem

- A Stoping second hand and time setting B Instant date correction C Manual winding

- 1 Correcting lever mounted 2 Minute wheel with pinion 3 Center canon with pinion 4 Double calendar wheel

- 5 Date indicator driving wheel 6 Fourth wheel with pinion and canon

Escapement

The escape wheel is made of steel and has 21 teeth

Balance and spring

The non magnetic assembly is comprised of a compensating flat balance spring and a beryllium-bronze screwless four armed balance. Equipoising is accomplished by milling the lower face of the rim.

Shock-protecting device

Incabloc, both units are pressure set into the plate and balance bridge respectively.

Movable stud holder

This allows the balance to be quickly and accurately set in beat without disassembling the balance bridge.



Regulating device

The regulator is of the two-piece type, permitting wide displacements of the keyholder on adjusting.

The adjuster for the regulator permits very close timing corrections.


Calendar device

The hour wheel meshes with the double calendar setting wheel, and the pinion of the setting wheel gears with the date indicator driving wheel.

A cam with date finger is mounted on the date indicator driving wheel which performs a complete revolution every 24 hours thus causing a new date to appear in the dial window.

The combination of cam, lever and spring permits an instant jump of the date indicator.





Date correction

By pulling the winding crown into position 2 (intermediate position), the clutch wheel meshes with the setting wheel and consequently with the date corrector (starwheel).

By revolving the winding crown either clockwise or anti-clockwise the date corrector conducts the date indicator in both directions. Every date-change is securely positioned by the date jumper guard.

Stop-second

The winding crown pulled into position 3 will automatically stop the second hand.

Hand setting

With the winding crown drawn into position 3 the correcting lever transmits its movement, over a pin traversing the plate, to the stop lever which is placed underneath the train wheel bridge. The stop lever carries a friction spring that blocks the rim of the balance, while the hands can be set to the correct time.

To restart the movement the winding crown is pushed towards the case.

Fitting the hands

The hands have to be fitted exactly after the date has changed at midnight.

It will be necessary to fit all the three hands before placing the automatic assembly.

Automatic device

For functional description of the mechanism, similar to calibre 550, refer to 'TG 13'. The rotor consists entirely of heavy metal.

Disassembling the automatic block

After unscrewing the gib, the rotor can be lifted off. The block is carefully removed sideways (movement uncased).

Placing the automatic block

When placing the automatic block, the following procedure should be applied (movement cased up):

- 1. Unwinding the mainspring
- 2. Removing ratchet wheel
- 3. Placing complete rotor
- 4. Replacing ratchet wheel

Lubrification of the movement

Epilaming

The following parts are treated by a new system of epilaming that resists the cleaning and rinsing solutions normally used by watchmakers.

Ebauches

Plate Barrel bridge Train wheel bridge Pallet cock Rotor with pinion Upper bridge for automatic device Lower bridge for automatic device Date indicator guard

Movement parts

Ratchet wheel
Crown wheel
Crown wheel core
Wig-wag pinion
Barrel drum
Barrel cover
Center wheel with pinion
Minute wheel with pinion
In-settings lower and upper for Incabloc
Rotor axle
Winding pinion
Large wheel of winding wheel Small
wheel of winding wheel

Date indicator driving wheel
Winding stem
Third wheel with pinion
Third wheel canon
Fourth wheel with pinion
Center second pinion with ring
Center second friction spring
Center cannon wheel with tube
Escape wheel with pinion
Cap jewel for balance upper, lower
Driving gear for ratchet wheel
Gib of rotor
Double calendar wheel

Remarks

To prevent destruction of the epilame-coating we propose the utilisation of cleaning fluids whose pH is inferior to 10 (pH control paper is available from our Service Department).

As rinsing baths we recommend:

Benzine 110-140 Isopropylic alcohol Benzine 80-95 Trichlorethylene Perchlorethylene

The epilam-coating is destroyed by the solvant Freon and cleaning fluids whose pH is superior to 10.

Lubrification of the movement

Selflubricant 3.03

Slip-ring of barrel drum
Winding pinion
Clutch wheel
Setting lever stud and beak
Setting lever spring
Pressure spring for setting lever
Yoke
Yoke spring

Came and lever of driving wheel Came lever spring Date jumper Date jumper spring Beak of date jumper (inclination) Correcting lever mounted Correcting lever spring Setting lever

Oil F 1.00

Pivoting of barrel arbor
Pivoting of center wheel
Pivoting of third wheel
Pivoting of fourth wheel
Pivoting of scapement wheel
Pivoting of balance wheel
Ring of center second pinion
Friction spring-center second pinion
Wig-wag pinion
Wig-wag spring
Hole of upper and lower winding gear
Teeth of large and small winding wheel for winding gear
Post for double calendar wheel

Selflubricant 3.02

Sattelites of winding gear

Oil 1% F 1.01

Pivoting of lever Pivoting of corrector (starwheel)

The parts of the winding and date mechanism are selflubricated as per method SL 3.03 and can be washed in ultrasonic cleaning machines. The time of the ultrasonic cleaning operation should however not exceed the normal cleaning cycle of the machine.

Post for date indicator driving wheel
Third wheel canon
Center tube-center wheel
Winding stem
Post for correcting lever
Post for minute wheel
Seat for crown wheel
Crown wheel core
Intermediate crown wheel
Pivoting of ratchet driving wheel
Pivoting of winding gear
Pivoting of driving wheel for winding gear
Rotor axle
Gib of rotor
Post for date jumper

Grease F (GF) 2.00

Pallet stones Center wheel-canon pinion