# SEIKO

## DIGITAL QUARTZ

Cal. L423A

## Cal. L423A







4001 183



4219 181



4245 181



4270 181



4313 180



☆4510 051



4521 181



☆SEIKO TR721SW

## Cal. L423A

#### Characteristics:

Casing diameter:

φ 16.0 mm

Maximum height:

3.4 mm without battery

Frequency of quartz crystal oscillator: 32,768 Hz (Hz=Hertz.... Cycles per second)

Time and calendar display: Digital display system showing hour (12-hour indication), minute, second, month, date and

day of the week.

Display medium: Nematic Liquid Crystal, FE-Mode.

Regulation system: Trimmer condenser

Battery life indicator: All the digits in the display begin flashing.

PART NO.	PART NAME	PART NO.	PART NAME
4001 183	Circuit block		
4219181	Battery connection insulator		
4245 181	Switch spring		
4270 181	Battery connection (-) Connector		
4313 180	Liquid crystal panel		
¼4510 051	Liquid crystal panel		
4521 181	Reflecting mirror		
SEIKO TR721SW )	Silver (II) oxide battery		
Nihon-Denchi SR721SW	Silver oxide battery		
•			

#### Remarks:

#### Liquid crystal panel

Be sure that combination between the color of panel cover and liquid crystal panel ☆4510 051 } should be matched according to the "SEIKO Quartz Casing Parts List". ☆4510 052

### Battery

- **☆SEIKO TR721SW**
- ☆ SEIKO SB-DK
- ☆ Nihon-Denchi SR721 SW

The substitutive battery might be added to the applied battery in the future. ....In that case, please refer to separate "BATTERY LIST FOR SEIKO

QUARTZ WATCHES". Note that SEIKO battery is marked with "SEIZAIKEN" on its (+) side.


☆⇔Please see remarks.


Part numbers in light letters are not shown in photos.

## TECHNICAL GUIDE

# SEIKO DIGITAL QUARTZ

CAL.L423A






#### **CONTENTS**

I.	. SPECIFICATIONS	1
H.	STRUCTURE OF THE CIRCUIT BLOCK	1
111.	DISASSEMBLING AND REASSEMBLING	2
	1. Líquid crystal panel side	2
	2. Switch mechanism	3
	3. Segment (Liquid crystal panel electrode)	. 4
IV.	CHECKING AND ADJUSTMENT	. 5
	Check battery voltage	. 5
	Check pattern segment checking system	. 5
	Check conductivity of liquid crystal panel, circuit block and connectors	. 5
	Check liquid crystal panel and circuit block	. 5
	Check current consumption	. 6
	Check conductivity of switch components	. 6
	Check accuracy	. 6
	Check functioning and adjustment	. 6

#### I, SPECIFICATIONS

Cal. No.	L423A	
Item		
Display medium	Nematic Liquid Crystal, FEM (Field Effect Mode)	
Liquid crystal driving system	Multiplex driving system	
Display system	Time and calendar function (The display is shown for 2 seconds automatically in the following order by depressing a button. Second — Month/Date — Day)	
Additional mechanism	Battery life indicator	
Loss/gain	Loss/gain at normal temperature range Monthly rate: less than 15 seconds (Annual rate: less than 3 minutes)	
Casing diameter	$\phi$ 16.0mm $\left($ 13,0mm between 6 o'clock and 12 o'clock sides $ ight)$ 15,5mm between 3 o'clock and 9 o'clock sides $ ight)$	
Height	3.4mm without battery	
Regulation system	Trimmer condenser	
Measuring gate by Quartz Tester	Any gate is available,	
Battery	SEIKO (SEIZAIKEN) TR721SW or SB-DK, or Nihon-Denchi SR721SW Battery life is approximately 2 years. Voltage: 1.55V	

## II. STRUCTURE OF THE CIRCUIT BLOCK




#### III. DISASSEMBLING AND REASSEMBLING

Disassembling procedures Figs.: ① → ⑦


Reassembling procedures Figs.: ⑦ → ①

1. Liquid crystal panel side




#### 2. Switch mechanism


• How to disassemble the switch spring



Put the tip of the tweezers in the clearance between the battery guard and switch spring and pry up the switch spring for disassembling.




#### · How to reassemble the switch spring




While sliding the switch spring from the arrow-mark direction, set the and B portions in the battery

Then, while setting © portion by pushing the switch spring from the side, push ① portion by the tweezers and set the switch spring into the battery guard.


How to reassemble the battery connection (—) and the battery connection insulator.



- Sat the battery connection insulator on the battery connection (-) according to the same procedures.









- ~(Battery guard)
- 7 Circuit block (with battery guard and liquid crystal panel frame)
- The battery guard and liquid crystal parel frame are fixed on the circuit block tightly and they cannot be disassembled.

#### 3. Segment (Liquid crystal panel electrode)


• Designation of segment





Common electrode 1 is connected electrically with segment.

Common electrode 2 is connected electrically with segment.



4

#### IV. CHECKING AND ADJUSTMENT

• Refer to the "SEIKO QUARTZ TECHNICAL GUIDE, GENERAL INSTRUCTION for Digital Watches" for


#### Procedure

#### CHECK BATTERY VOLTAGE

#### Result:

More than 1,5 V . . . . Normal Less than 1.5 V . . . . Defective

#### CHECK PATTERN SEGMENT CHECKING SYSTEM




- Depress button A for 4 to 5 seconds, and all the segments light up.
- With all the segments lit, check to see if there is any defective segment. Depress either button A or B to return the time display.

#### CHECK CONDUCTIVITY OF LIQUID CRYSTAL PANEL, CIRCUIT BLOCK AND CONNECTORS


#### CHECK LIQUID CRYSTAL PANEL AND CIRCUIT BLOCK

• How to check the output voltage for the circuit block.



#### Result:

More than 0.8 V . . . . Normal Less than 0.8 V . . . . Defective




#### Check the liquid crystal panel

#### Result:

Lights up . . . . . . . Normal Does not light up . . . . Defective

#### CHECK CURRENT CONSUMPTION

· Check the current consumption of the module after removing the switch spring, battery connection insulator, and battery connection (-).



#### Result:

Less than 1.0µA . . . Normal \*More than 1.0µA...Defective

\*How to identify if the liquid crystal panel or circuit block is deffective when the current consumption is more than 1.0µA.

Disassemble the liquid crystal panel, reflecting mirror and connectors, and measure the current consumption.

#### Result:

Less than  $0.8\mu A\dots$  Replace the liquid crystal panel with a new one.

More than 0.8 µA . . , Replace the circuit block with a new


#### CHECK CONDUCTIVITY OF SWITCH COMPONENTS

#### CHECK ACCURACY

• Depress button A for 4 to 5 seconds, and all the segments light up. That facilitates measuring the daily rate.

#### CHECK FUNCTIONING AND ADJUSTMENT

• Depress button B and check to see if each display is shown for 2 seconds and automatically changed in the following order.



- Depress button B twice and check to see if the time display will return after the seconds are displayed for 4 to 5 minutes.
- Check to see if each display starts flashing to be adjusted by each depression of button A.
- Check to see if the flashing digit is advanced by each depression of button B.

All procedures of Disassembling, Reassembling, Checking and Adjustment are completed.