



















A



B

2000.574.G 1.		Main plate
3305.275.CO 2.		Cannon pinion with driver (Aig.1)
2030.017.CO 3.		Centre bridge Centre bridge held by 1 screw 4000.250.
4000.250 4.		Screw
3001.055.FI 5.		Sliding pinion
3000.177.CO 6.		Setting stem
3017.049 7.		Setting lever
3905.049 8.		Setting lever jumper (3 positions) Setting lever jumper held by 1 screw 4000.250.
4000.250 9.		Screw
3015.081 10.		Yoke (3 positions) Parts 3015.081 and 3905.067 must be exchanged together.
3905.067 11.		Yoke spring Tensioning the spring arm. Parts 3015.081 and 3905.067 must be exchanged together.
3406.030 12.		Pusher jumper B Put the grey jumper between the two posts on the further side.
3406.038 13.		Pusher jumper A Put the yellow jumper between the two posts on the closer side.
3622.040 14.		Stator Mark [Z] on stator.
3622.039 15.		Stator (counter 6h, 9h and chrono)
3622.039 16.		Stator (counter 6h, 9h and chrono)



C


3603.079  
17.  Plastic bracket  
Plastic bracket held by 4 screws 4000.250.


4000.250  
18.  Screw

3715.094.RK  
19.  Rotor


3715.094.RK  
20.  Rotor


3147.046.CO  
21.  Intermediate wheel

3136.142.CO  
22.  Second wheel (long)




D


3147.047.CO  
23.  Intermediate wheel (chrono)

3136.143.CO  
24.  Chronograph wheel (Aig.1)


3122.056.CO  
25.  Third wheel




E


2020.148.G  
26.  Train wheel bridge  
Train wheel bridge held by 3 screws 4000.250.

4000.250  
27.  Screw

3715.095.RK  
28.  Rotor  
Parts 3612.144.5021, 3715.095.RK and 3147.048.CO must be exchanged together.

3147.048.CO  
29.  Intermediate wheel (counter)  
Parts 3612.144.5021, 3715.095.RK and 3147.048.CO must be exchanged together.

3402.006.CO  
30.  Minute counting wheel



F

2020.149.G  
31.



Counter train wheel bridge  
Counter train wheel bridge held by 3 screws 4000.250.

4000.250  
32.



Screw

4000.250  
33.



Screw

3621.053.RK  
34.



Coil  
Attention: Please hold the coil only on the grey coil core. Coil held by 1 screw 4000.250.

3621.054.RK  
35.



Coil (counter 9h, chrono)  
Attention: Please hold the coil only on the grey coil core. Coil held by 1 screw 4000.250.

3621.054.RK  
36.



Coil (counter 9h, chrono)  
Attention: Please hold the coil only on the grey coil core. Coil held by 1 screw 4000.250.

4000.250  
37.



Screw

3601.118  
38.



Contact strip  
Contact strip held by 1 screw 4000.250.

4000.250  
39.




Screw

3603.034  
40.



Battery insulator



G

3612.144.5021  
41.



Electronic module  
Electronic module held by 5 screws 4000.248. Electronic measurements may be realised now. Parts 3612.144.5021, 3715.095.RK and 3147.048.CO must be exchanged together.

4000.248  
42.



Screw

3603.069  
43.




Circuit insulator


3601.107.G  
44.



Pusher contact spring



H




2130.137.G.M01.5021D  
45.  **Electronic module cover**  
Electronic module cover held by 3 screws 4000.250.





3600.010.HGF  
46.  **Battery 395**


3601.109.G  
47.  **Bridle +**  
Bridle held by 1 screw 4000.250.

4000.250  
48.  **Screw**









J

2000.574.G 49.		Main plate
3004.164 50.		Setting wheel
3004.164 51.		Setting wheel
3007.054.CO 52.		Minute wheel





K

2130.143 53.		Minute train bridge Minute train bridge held by 2 screws 4000.305.
4000.305 54.		Screw
3301.241 55.		Hour wheel (Aig.1)
3315.016 56.		Friction spring
3004.224.CO 57.		Date indicator driving wheel
3500.049 58.		Date jumper











L


3504.208.AB.1.A 59.		Date indicator (standard) Nick of the indicator at 3 o'clock.
2130.141 60.		Date indicator maintaining plate Date indicator maintaining plate held by 1 screw 4000.250.




M

3905.070 61.		<b>Date jumper spring</b> Insert the date jumper spring in the provided opening.
2130.140.G 62.		<b>Date mechanism maintaining plate</b> Date mechanism maintaining plate held by 2 screws 4000.250.
4000.250 63.		<b>Screw</b>
3506.072.G 64.		<b>Dial support</b>
8200 65.		<b>Moebius 8200</b>
9014 66.		<b>Moebius 9014</b>
124 67.		<b>Jismaa 124</b>
9020 68.		<b>Moebius 9020</b>






Battery	<b>395</b>
Voltage	<b>1.55 V</b>




*Setting stem in position I, calendar not in gear,  
60 s measuring interval for rate and consumption:*

Typical consumption	<b>1.32 <math>\mu</math>A</b>
Maximal consumption	<b>1.65 <math>\mu</math>A</b>
Instantaneous rate	<b>-10s/M. .. +20s/M.</b>
Lower working voltage limit	<b>1.30 V</b>



*Setting stem in position III, 60 s measuring interval:*


Typical consumption	<b>0.10 <math>\mu</math>A</b>
Maximal consumption	<b>0.30 <math>\mu</math>A</b>




Coil resistance M1 **1.90 k $\Omega$  .. 2.10 k $\Omega$**

Coil resistance M2 **2.20 k $\Omega$  .. 2.40 k $\Omega$**

Coil resistance M4 **2.20 k $\Omega$  .. 2.40 k $\Omega$**



Coil resistances M1-M4  **$\infty$  k $\Omega$**



*Signal generator (4.9 ms, 8 Hz):*

Lower working voltage  
limits M2-M4 **1.30 V**